PREMIER®

MANUAL DE INSTRUCCIONES
RIZADOR DE CABELLO
ADC-4861CR

ESTIMADO CLIENTE

Con el fin de que obtenga el mayor desempeño de su producto, por favor lea este manual de instrucciones cuidadosamente antes de comenzar a utilizarlo, y guárdelo para su futura referencia.
Si necesita soporte adicional, no dude en escribir a: ***info@premiermundo.com***

ÍNDICE

INSTRUCCIONES DE SEGURIDAD 2
INSTRUCCIONES DE OPERACIÓN 2
LIMPIEZA Y MANTENIMIENTO 2
ESPECIFICACIONES 3


PRECAUCIÓN
RIESGO DE CHOQUE ELÉCTRICO , NO ABRA
Precaución: Para reducir el riesgo de choque eléctrico, no retire la cubierta, no hay partes manipulables por el usuario al interior de la unidad. Refiera todo mantenimiento o intervención técnica a personal técnico calificado.
Este símbolo indica la existencia de voltaje peligroso al interior de esta unidad, que constituye un riesgo de choque eléctrico.
Este símbolo indica que hay importantes instrucciones de operación y mantenimiento en la literatura que acompaña a esta unidad.

LÍNEAS DE SERVICIO AL CLIENTE PREMIER

Venezuela:	0800 – ELECTRIC (353-2874)
Panamá:	300-5185
Sitio Web:	www.premiermundo.com
E-mail:	servicioalcliente@premiermundo.com

NOTA
Nos reservamos el derecho de modificar las especificaciones, características y/u operación de este producto sin previo aviso, con el fin de continuar las mejoras y desarrollo del mismo.

⚠INSTRUCCIONES DE SEGURIDAD

- No utilice la unidad cerca de fuentes de agua como la bañera, el lavamanos o recipientes con agua.
- Desconecte el cable de poder del tomacorriente cuando no la esté utilizando.
- No coloque objetos pesados sobre el cable de poder.
- No utilice la unidad si observa que el cable de poder o el enchufe se encuentran dañados.
- No utilice la unidad cerca de materiales inflamables como benzina, tiner o sprays.
- La unidad no debe ser utilizada por personas (incluyendo niños) con capacidades físicas o mentales reducidas o falta de experiencia y conocimiento a menos que estén con una persona capacitada para supervisar.
- Mantenga la unidad fuera del alcance de los niños.
- No coloque la unidad en el baño o en un lugar con alta humedad.
- No utilice la unidad con las manos mojadas.
- Utilice la unidad frente a un espejo para asegurarse de no quemar accidentalmente su piel.
- Utilice la unidad únicamente con cabello humano. No la utilice en niños.
- El peinado durará por 1 día. El cabello regresará a su condición normal después de ser lavado.
- La unidad no es apta para personas con cabello demasiado crespo o rizado.
- Recuerde que la unidad se calienta bastante cuando está en uso. Tenga precaución con su piel.
- No coloque la unidad directamente sobre una superficie cuando esté caliente o esté conectada. Utilice la base para apoyarla.

INSTRUCCIONES DE OPERACIÓN

1. El cabello debe estar limpio, seco o casi seco y sin enredos antes de utilizar la unidad. (La unidad puede utilizarse en cualquier momento para retoques rápidos.)
2. Desenrolle completamente el cable de poder y conéctelo al tomacorriente.
3. Coloque el interruptor en la posición de encendido.
4. Espere unos minutos para permitir que la unidad alcance la temperatura de operación.
5. Separe los mechones de cabello que va a rizar y peine suavemente para que no esté enredado.
6. Agarre el cabello con la unidad y enrolle hacia la raíz. Tenga precaución de que la unidad no toque su piel ya que se calienta bastante.
7. Mantenga el rizador en esta posición por 10 o 20 segundos y luego desenrolle suavemente.
8. El cabello delgado requiere menos tiempo que el cabello grueso para obtener el efecto deseado. El regulador de temperatura le dará el efecto que desee sin importar su tipo de cabello. Haga un intento en un área pequeña para asegurarse de obtener los resultados que desea.

LIMPIEZA Y MANTENIMIENTO

- Antes de limpiar la unidad asegúrese de que está fría y desconectada. Limpie la manija con una prenda seca y suave. No se requiere ningún otro mantenimiento.
- Desconecte de la unidad cuando no la esté utilizando. Permita que se enfríe y luego almacénela en un lugar seguro y seco y fuera del alcance de los niños.
- No enrolle el cable alrededor de la unidad ya que puede romperse internamente.

ESPECIFICACIONES

Suministro de Energía	AC 110/220V – 60/50Hz
Consumo de energía	35W
Temperatura de operación	200ºC
Tiempo de elevación de temperatura	<4 minutos




Amortiguador (anillos de ferrita)
Pinza amortiguadora
Receptor de prueba EMI
EUT
Transformador
Pinza amortiguadora movida sobre el cable de poder para obtener máxima lectura o recepción
Cable de Poder
Transformador de Corriente
Amortiguador (anillos de ferrita)
El transformador para proporcionar voltaje estable a EUT durante la prueba

PREMIER®

INSTRUCTION MANUAL
HAIR CURLER
ADC-4861CR

DEAR CUSTOMER

In order to achieve the best performance of your product, please read this instruction manual carefully before using, and keep it for future reference.
If you need extra support, please write to ***info@premiermundo.com***



CAUTION

RISK OF ELECTRIC SHOCK, DO NOT OPEN

Caution: To reduce the risk of electric shock do not open this device, there are not serviceable parts for customers. Please refer any maintenance or repair to qualified personnel.

This sign means the existence of dangerous voltage at the inside of the unit, which states a risk of electric shock.

This sign means that there are important instructions of operation and handling in the manual that comes with this device.

PREMIER CUSTOMER SERVICE

Venezuela:	0800 – ELECTRIC (353-2874)
Panama:	300-5185
Website	www.premiermundo.com
E-mail:	servicioalcliente@premiermundo.com

NOTE
This unit may be submitted to changes in specifications, characteristics and/or operation without prior notice to the user, in order to continue improving and developing its technology.

USER MAINTENANCE

Always turn the Iron off when not in use.Any other servicing should be performed by an authorized service representative.

STORAGE

When not in use, your appliance is easy to store. Allow unit to cool; then simply put back in the box, and store out of reach of children in safe, dry location. Do not jerk or strain cord at plug connections.

WARRANTY

No warranty is expressed or intended.However, if prescribed maintenance and use conditions are met. Any unit found to be defective due to faulty workmanship after adhering to the following procedures:

1 . User/owner must keep unit clean at all timesand free of foreign objects, i.e. dirt, lint and contamination of any type.
2. Do not immerse or use near or in water.
3. Protect unit from moisture in any form at all times.
4. Protect unit from electrical overload, surge of inadequate electrical supply.
5. Keep electrical cord from curling, kinking, or unnecessary twisting.

IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, especially when children are present, basic safety precautions should always be followed, including the following:

Read all instructions before using

KEEP AWAY FROM WATER

Danger - as with most electrical appliances,electrical parts in this iron are electrically live even when the switch is off:

• Always unplug immediately after using
• Do not use while bathing
• Do not place or store appliance where it can fall or be pulled into a tub or sink.
• Do not place in or drop into water or other liquid
• If appliance falls into water unplug it immediately.

Do not reach into the water.

WARNING: To reduce the risk of burns,electrocution, fire or injury to persons:

• An appliance should never be left unattended when plugged in.
• Close supervision is necessary when this appliance is used by, on, or near children or individuals with certain disabilities.
• Use this appliance only for its intended use as described in this manual. Do not use attachments not recommended by the manufacturer.
• Never operate this appliance if it has a damaged cord or plug, if it is not working properly, or if it has been dropped, damaged, or dropped into water. Return the appliance to a service center for examination and repair.
• Keep the cord away from heated surfaces. Do not wrap the cord around the appliance.
• Never block the air openings of the appliance or place it on a soft surface, such as a bed or couch,where the air openings may be blocked. Keep the air openings free of lint, hair, and the like.
• Never use while sleeping.
• Never drop or insert any object into any opening or hole.
• Do not use outdoors or operate where aerosol (spray) products are being used or where oxygen is being administered.

• Do not use an extension cord with this appliance.
• NEVER use the device in water or other liquids.
NEVER use the device near a bathtub, shower,containers full of water, or any other damp place.
Never use it with bare feet or when hands andfeet are wet.
• Do not place the hot **curling iron** on plastic or any material sensitive to heat.
• **Do** not touch **the curling iron** when it is hot.Always be very careful not to burn yourself when styling.
• Do **not** use **the** appliance **for** any other purpose than its intended use.
• To avoid risk of electric shock, this appliance is only used on dry hair, not for any wet or damp hair

HOWTO USE

1. For best results, wash, comb and dry hair until just damp to touch. Although the curling iron can be used at any time.
2. Fully unwind the mains cable.
3. Plug the styler into the mains and switch on at the socket.
4. Wait for a couple of minutes to allow the appliance to reach its working temperature.
5. Separate the strands of hair to be curled and gently brush free of tangles.
6. Grip the hair using the clamp and wind towards the scalp. Do not allow the barrel to come into contact with your skin as it is very hot.
7. Hold the curling iron in this position for 10-20 seconds and then gently unwind.
8. Fine hair requires less time than thick hair to create the desired effect.The temperature regulator will give you the desired effect whatever type of hair. Always experiment on a small area of hair first to ensure you see the results you want.

TECHINCAL DETAILS

Power supply:AC110V~220V 60/50Hz
Average power consumption:35W
Operation temperature:200□
Temperature rise timer:<4minutes

MORE DETAILS FOR YOUR CURLER




Absorber
(ferrite rings)
Absorbing
clamp
EMI test
receiver
EUT
Transformer
Absorbing clamp
moved over power
cord to obtain max.
reading o receiver
Mains
Current
transformer
Absorber
(ferrite rings)
The transformer to provide
a stable voltage to the EUT
during the test.